

MPU080 Install Instructions

The Rottendog Amusement MPU080 MPU board for Gottlieb system 80 and 80A pinball games comes “almost” plug-and-play, when it comes to install; However, there are a few things that must be done, or should be checked prior to home install. These things are:

On your original MPU board, you will have a bank of 4 DIP switches labeled SW1 – SW4 in the lower left side of the board. Set the DIP switches on the new MPU080 board to exactly match the original switch settings.

On the new MPU080 set DIP switch SW5 to your specific game title. Note the LARGE 0 and LARGE 1 stenciled in white on the board itself. Use these to set all DIP switch locations.

Swap the new MPU080 board for the old Gottlieb S80 MPU.

1/4/2017